

Panneaux de pont

Deck hatches



18

Guide de sélection

Selection guide

Gamme Range	Ouvrant Lid	Dormant Lower frame	Sens d'ouverture Opening side	Montage Assembly	Finition Finish	Implantation à bord / zone CE CE-approved for location on board	
OPAL	Profilé Extrusion	Profilé Extrusion	Extérieur Outwards	A visser Screws	Satiné, brillant, ou peint Satin, shiny or powder coated	II, III & IV	Zones pont, roof et cockpit All categories
INTEGRATION	Glace Acrylic	Fonderie Casting	Extérieur Outwards	A coller Glue	Satiné Satin	II, III & IV	Zones pont, roof et cockpit All categories
CRISTAL	Fonderie Casting	Profilé Extrusion	Extérieur Outwards	A visser Screws	Satiné Satin	II, III & IV	Zones pont, roof et cockpit All categories
						I	Trappe de survie Escape hatch

Les zones à bord selon la norme Européenne CE 94/25 du 16 Juin 1996 :

- Zone I : coque au-dessus de la ligne de flottaison
- Zone II : pont, roof, cockpit, tableau arrière
- Zone IIb : zone de la coque n'appartenant pas à la zone I
- Zone III : superstructure, pont et cockpit
- Zone IV : cockpit et pont, faces arrière de la superstructure

Areas on board as per 94/25 EC standard of 16 June 1996 :

- Area I : hull above waterline
- Area II : deck, coachroof, cockpit and transom
- Area IIb : hull sections outside area I
- Area III : superstructure, deck and cockpit
- Area IV : cockpit and deck, rear faces of superstructure